



JBL PartyBox Encore User Guide

[Home](#) » [JBL](#) » JBL PartyBox Encore User Guide



Contents [[hide](#)]

- [1 JBL PartyBox Encore User Guide](#)
- [2 WHAT'S IN THE BOX](#)
- [3 Bluetooth Pairing](#)
- [4 Play](#)
- [5 Lightshow](#)
- [6 APP](#)
- [7 Microphone](#)
- [8 True Wireless Stereo](#)
- [9 Charging](#)
- [10 Splash proof IPX4](#)
- [11 TECH SPEC](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

JBL PartyBox Encore User Guide



WHAT'S IN THE BOX




* Power cord quantity and plug type vary by regions.

** MICROPHONE QUANTITY VARY BY REGIONS.

Bluetooth Pairing



Play



Lightshow



APP



Microphone



True Wireless Stereo



Charging




Splash proof IPX4



TECH SPEC

Transducers:	1 x 5.25 inch woofer, 2 x 1.75 inch tweeter	Bluetooth® transmitter frequency range:	2.4 GHz - 2.4835 GHz
Output power:	100 W RMS	Bluetooth® transmitter power:	< 9 dBm (EIRP)
Power input:	100-240 V ~ / 50-60 Hz	Bluetooth® transmitter modulation:	GFSK, π/4 DQPSK, 8DPSK
Frequency response:	50 Hz - 20 kHz @-6 dB	Product dimensions (W x H x D):	276 mm x 327 mm x 293 mm / 10.87" x 12.87" x 11.54"
Signal-to-noise ratio:	> 80 dB	Net weight:	6.3 kg / 13.89 lbs
Battery type:	Li-ion polymer 27.0 Wh (equivalent to 3.6 V / 7500 mAh)	Packaging dimensions (W x H x D):	472 mm x 354 mm x 326 mm / 18.58" x 13.94" x 12.83"
Battery charge time:	3.5 hours	Gross weight:	8.34 kg / 18.39 lbs
Music play time:	up to 10 hours (dependent on volume level and audio content)	Wireless microphone spec	
USB format:	FAT16, FAT32	Frequency response:	60 Hz - 15.8 kHz
USB file format:	.mp3, .wma, .wav	Signal-to-noise ratio:	> 65 dB
USB charge out:	5 V / 0.5 A (maximum)	Transmitter transmitting power:	< 10 mW
Cable type:	AC Power Cable	Distance between transmitter and receiver:	≤ 20 m
Cable length:	2000 mm / 78.7"		
Bluetooth® version:	5.1		
Bluetooth® profile:	A2DP 1.3, AVRCP 1.6		



Note: The product is in compliance with the European Union energy legislation. 1) Bluetooth/TWS connection mode The product is intended to be used for streaming music via Bluetooth connection. A consumer can stream Bluetooth audio to the speaker. When the product is connected through Bluetooth, the Bluetooth connection must remain active at all times to ensure proper operation. The product will enter sleep mode (networked standby) after 20 minutes without operation. The power consumption in sleep mode is less than 2.0 Watts, after which it can be re-activated via Bluetooth connection. 2) Other mode The product will enter standby mode after 20 minutes without operation. The power consumption in standby mode is less than 0.5 Watts. The maximum operation temperature is 45 °C No naked flame sources, such as lighted candles, should be placed on the apparatus.



This equipment is a Class II or double insulated electrical appliance. Активная



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.





Read More About This Manual & Download PDF:

Documents / Resources



[JBL PartyBox Encore](#) [pdf] User Guide
PartyBox Encore, PartyBox, Encore, Party Speaker, Speaker