<u>Manuals+</u> — User Manuals Simplified.



JBL Pulse 5 Portable Bluetooth Speaker User Guide

Home » JBL » JBL Pulse 5 Portable Bluetooth Speaker User Guide



JBL Pulse 5 Portable Bluetooth Speaker User Guide

Contents [hide

- WHAT'S IN THE BOX
 Bluetooth pairing
 Play
 Party Boost
 APP
 Light Show
- 7 Charging
- 8 IP67 dustproof & Waterproof
- 9 TECH SPEC
- 10 Documents / Resources
- 10.1 References
- **11 Related Posts**

WHAT'S IN THE BOX



Bluetooth pairing



Play



Party Boost









Use the JBL PORTABLE app for speaker configuration and software upgrade.



Light Show





APPLY LIGHTSHOW PRESETS AND MORE WITH THE JBL PORTABLE APP

Charging



IP67 dustproof & Waterproof



TECH SPEC

Transducers: 1 x 64 mm woofer / 2.5", 1 x 16 mm tweeter / 0.63" **Output power:** 30 W RMS for Woofer, 10 W RMS for Tweeter Power input: 5 V / 3 A Frequency response: 58 Hz – 20 kHz (axial, -6 dB) Signal-to-noise ratio: > 80 dB Battery type: Li-ion polymer 27 WH (equivalent to 3.6 V / 7500 mAh) Battery charge time: < 4 hours (5 V / 3 A) Music play time: up to 12 hours (dependent on volume level and audio content) Cable type: USB-C charging cable Cable length: 1200 mm / 47.2" Bluetooth® version: 5.3 Bluetooth® profile: A2DP 1.3, AVRCP 1.6 Bluetooth® transmitter frequency range: 2.4 GHz - 2.4835 GHz Bluetooth® transmitter power: < 10 dBm (EIRP) **Bluetooth® transmitter modulation:** GFSK, π/4 DQPSK, 8DPSK 2.4GHz SRD frequency range: 2407 MHz – 2475 MHz SRD transmitter power: ≤ 13 dBm (EIRP) Product dimensions (W x H x D): 107 mm x 214 mm x 131 mm / 4.2" x 8.5" x 5.2" Net weight: 1.47 kg / 3.23 lbs Packaging dimensions (W x H x D): 254 mm x 145 mm x 143 mm / 10" x 5.7" x 5.6" Gross weight: 2.2 kg / 4.8 lbs Maximum operation temperature: 45 °C



To protect battery lifespan, fully charge at least once every 3 months. Battery life will vary due to usage patterns and environmental conditions.

Do not expose the JBL Pulse 5 to liquid without removing cable connection and ensure the charging port lid is tightly closed. Do not expose JBL Pulse 5 to water while charging. It may result in permanent damage to the speaker or power source.

Chemicals, salt or "foreign particles" in your pool or the ocean can damage the waterproof seals or harm the connector surface over time if not rinsed off after use.

After a liquid spill or rinse, do not charge your speaker until it's completely dry and clean. Charging when wet might damage your speaker.

When using an external adapter, the output voltage/current of the external adapter should not exceed 5V/3A.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.



Documents / Resources

OUICK START GUIDE	JBL Pulse 5 Portable Bluetooth Speaker [pdf] User Guide Pulse 5, Portable Bluetooth Speaker, Pulse 5 Portable Bluetooth Speaker, Bluetooth Speaker, Speaker	
	JBL Pulse 5 Portable Bluetooth Speaker [pdf] User Guide JBLPULSE5, APIJBLPULSE5, Pulse 5 Portable Bluetooth Speaker, Pulse 5, Portable Bluetooth Speaker, Bluetooth Speaker, Speaker	
OUICK START GUIDE	JBL Pulse 5 Portable Bluetooth Speaker [pdf] User Guide Pulse 5 Portable Bluetooth Speaker, Pulse 5, Portable Bluetooth Speaker, Bluetooth Speaker, Speaker	

References

- © chemic.al
- O Welcome to nginx!
- O <u>Anatel Agência Nacional de Telecomunicações</u>
- Englishing Contract of the second secon

Manuals+, home privacy