



IPX7 Waterproof Bluetooth Speaker, 40W Portable Wireless Speaker, 32H Playtime, Stereo Loud Sound-Complete Features/Instruction Guide

[Home](#) » [Houl Zallee](#) » IPX7 Waterproof Bluetooth Speaker, 40W Portable Wireless Speaker, 32H Playtime, Stereo Loud Sound-Complete Features/Instruction Guide 

Contents

1 Houl Zallee

- 1.1 IPX7 Waterproof Bluetooth Speaker, 40W Portable Wireless Speaker, 32H Playtime, Stereo Loud Sound
- 1.2 Specifications
- 1.3 Introduction
- 1.4 HOW TO PAIR TWO BLUETOOTH SPEAKERS
- 1.5 HOW TO CONNECT
- 1.6 Frequently Asked Questions
- 1.7 Related Posts

Houl Zallee

IPX7 Waterproof Bluetooth Speaker, 40W Portable Wireless Speaker, 32H Playtime, Stereo Loud Sound



Specifications

- **BRAND:** Houli Zallee
- **COLOR:** Black
- **SPEAKER TYPE:** Outdoor, Stereo, Subwoofers
- **WATERPROOF:** IPX7
- **POWER SOURCE:** Battery Powered
- **PACKAGE DIMENSIONS:** 14.84 x 7.99 x 4.92 inches
- **ITEM WEIGHT:** 4.64 pounds
- **BATTERIES:** 1 Lithium Polymer battery

Introduction

This powerful Bluetooth speaker offers 40W surround sound (max 60W) and pumps out well-balanced midrange, clear treble, and punchy bass with virtually no distortion, allowing you to fully enjoy your music. Combine two speakers for 80 watts of stereo sound. On a single charge, the Houli Zallee outdoor Bluetooth speaker can play for up to 32 hours (Actual playtime may vary by the music content and sound volume). At home, in the garage, or on the road, enjoy the strong sound with powerful bass and clear vocals. It may also be used as a power bank to charge phones or other gadgets thanks to its built-in large-capacity rechargeable batteries, making it an excellent camping present. The Houli Zallee outdoor speaker has been extensively tested to fulfill IPX7 waterproof standards, making it ideal for outdoor adventures. It's completely waterproof and can float on water for up to 30 minutes after being fully submerged in 3.3 feet of water. As a result, there's no need to be concerned when using it near the sea, in a pool, on a boat, or in a shower.

The inspiration for outdoor activities. This wireless Bluetooth speaker features the latest Bluetooth 5.0 chip with EDR technology, which promises a faster and more stable connection than Bluetooth 4.0. Tailgate parties, birthday parties, pool/beach parties, backyard barbecues, and camping/hiking vacations are all made easier with the Houli Zallee bass Bluetooth speaker. This portable outdoor speaker is made of ultra-tough ABS and aluminum, making it extremely durable and impact-resistant. It's very easy to carry the speaker anywhere for outdoor sports or other activities, bringing a lot of pleasure with us, thanks to the built-in handle. This large speaker is an excellent present for men, women, teenagers, and the elderly who enjoy music.

HOW TO PAIR TWO BLUETOOTH SPEAKERS

1. Activate the two speakers.
2. Make sure the two speakers aren't connected to any devices (hold down the PAUSE button for a long time to disconnect the speakers from your smartphone).
3. Press and hold the + and – buttons on one speaker for a long time until you hear “DING.”
4. Go to your Bluetooth settings on your device, tap the speaker's name, and pair.

HOW TO CONNECT

1. Put the speaker in pairing mode first. Turn on the speaker and long-press the device's Bluetooth button.
2. Turn on Bluetooth on your smartphone. Select the Bluetooth settings to option in your phone's settings (both Android and iOS).
3. Hold your breath and wait for the phone to connect.

Frequently Asked Questions

- **On my IPX7 waterproof wireless speaker, how can I adjust the time?**

Hold down the M key until the clock symbol appears above the time. Press the play/pause/stop button until the time flashes after you see the clock icon above. When it starts flashing, you'll know it's time to take action. To set the time, use the volume up or down buttons.

- **Why isn't my Bluetooth speaker working?**

If your Bluetooth devices won't pair, it's probably because they're out of range or not in pairing mode. Try rebooting your devices or having your phone or tablet “forget” the connection if you're encountering persistent Bluetooth connection issues.

- **What is the best way to connect my Android to a wireless speaker?**

Set up your system using an Android phone, tablet, or Kindle Fire. In only a few minutes, use the Wi-Fi settings to join new speakers to the network. You're done once you've given the speaker a name. In the same method, you can add new speakers.

- **How do I activate Bluetooth?**

On an Android device, enable Bluetooth.

On your device, go for the Settings app and choose it.

Scroll down to Bluetooth or the Bluetooth icon and choose it.

Toggle Bluetooth to the on position.

- **What is the best way to connect my IPX7 wireless speaker?**

On one of the speakers, simultaneously press the “+” and “-” buttons. TWS pairing mode will be activated after the speaker plays an audio tone. 3. The two speakers will automatically pair after 1-2 seconds.

- **What's the best way to pair IPX7?**

To put the headphones into pairing mode, press and hold the MFB key for about 6 seconds. The LED light will alternately flash blue and red once in this mode. Select “AV: LINK SBH03” from your smart device's Bluetooth search feature, and the LED will blink blue when the device is paired.

- **What is the best way to connect your phone to a shower speaker?**

Pairing your Bluetooth speaker with your phone or another Bluetooth device Toggle the Bluetooth speaker's pairing mode on, turn it off and push and hold the ON/OFF button for around 6 seconds, or until the red and blue LEDs blink in succession.

- **What is the procedure for resetting my Bluetooth Shower Speaker?**

At the same moment, press and hold the button. The gadget has been reset and will switch off on its own. 3. Finally, push and hold the button to turn on the Bluetooth Speaker. Note: If the gadget is in good working order, do not reset it.

- **What is the best way to force a Bluetooth device to pair?**

After you've accessed Bluetooth settings, you'll need to locate your speaker (there should be a list of devices you have connected previously). If you want to connect, press and hold the top Bluetooth key until it starts up, then turn it on.

- **Why isn't Bluetooth able to locate devices?**

To reset Wi-Fi, mobile, and Bluetooth on an Android phone, navigate to Settings > System > Advanced> Reset Options > Reset Wi-Fi, mobile, and Bluetooth. To unpair all of your devices on iOS and iPadOS, go to Settings > Bluetooth, tap the info icon, then select Forget This Device for each device, then restart your phone or tablet.